

FIG. 1




FIG. 2




FIG. 3





FIG. 5



66

FIG. 7 is a block diagram of a user interface 700 for a television system. The user interface 700 includes a top bar 306, a main content area 301, and a bottom bar 302. The top bar 306 includes a logo 306, a user name field, a TV button, a Mail button, a Browser button, and a Help button. The main content area 301 includes a search bar 704, a change day button 702, and a stay on channel button 706. The bottom bar 302 includes a search bar 704, a change day button 702, and a stay on channel button 706.





FIG. 7



Bob234

Surf


TV

Mail

Help

Change Day

Search



Nickelodeon, Channel 18

Scruffy kids torment their parents and family dog.

6:30pm	7:00pm	7:30pm
grats	Doug	Hey Arnold!
A*S*H	Healthy Kids	Picket Fences ▲
me Savvy	How-2 Crew	Hometime
V Jams	Reindeer	BeatSuite
ewsters Millions		▲

FIG. 8




FIG. 9





FIG. 10



1100

FIG. 11




Fig. 12

Page 11 of 11
Printed on 11/11/2011 11:11:11 AM
Printed by: [illegible]




Fig. 13




Fig. 14




FIG. 15




Fig. 16




FIG. 17




FIG. 18




Fig. 19